

**Snap-on**  
**new product**

## Quick & Easy Operation **Cam Operated Valve Spring Compressor**

*Eliminates the need to remove cylinder*

*Eliminates the need to readjust tool to each spring*

*Works on most overhead valve engines*

### **Easy to Use**



1. Hold valve in place using air or an alternative means.
2. Keep cam handle of tool in the upright position.
3. Insert jaw into spring at the lowest coil, making sure the jaws are on opposing sides of the spring. The short jaw should be on the higher helix of the spring, the long jaw on the lower helix.
4. Adjust tool by turning the cam handle.
5. Compress spring by lowering the cam handle.
6. Tool is properly adjusted when the keepers are easily to remove.
7. To release pressure lift handle



*Blue-Point*

## **VST100** **Cam Operated** **Valve Spring Compressor**

 **WARNING**  
 • Wear safety goggles.  
(User & bystanders)