

SECURE VEHICLE GATEWAY

Using compatible diagnostic tools, now you can seamlessly connect to ____ secure vehicle gateways ___





CONNECTING YOUR DIAGNOSTIC TOOL FOR USE WITH SECURE VEHICLE GATEWAYS

What you need:

- · A compatible Snap-on diagnostic tool with Wi-Fi access
- · An authorized AutoAuth account(s)
- · A Snap-on® Profile Manager Account

Watch the Getting Connected video @

SNAPON.COM/GATEWAY

GETTING YOUR DIAGNOSTIC TOOL INFORMATION

Make sure your diagnostic tool is connected to Wi-Fi before you start!

You'll need some information from your diagnostic tool. Select "System Settings or Tools", then "Get Connected"



Remember your Device Information:
Serial number:
Pin Code:
Activation Code:



CREATING AN AUTOAUTH ACCOUNT

NOTE - AutoAuth charges a \$50 annual fee.

Make sure your diagnostic tool is connected to Wi-Fi before you start!

Go to autoauth.com and select "Register Now" and create an account.




Remember your Username and Password

2 Check your email and verify your account.

Login to autoauth.com and follow the link to complete your registration as a "Service Center Signup / Independent Technician Signup".

After entering the required information select "Sign Up".

Select the "Manage Tools" tab and enter the required information.



5 When done select "Add".

Add

Your AutoAuth account is now complete.

CREATING A SNAP-ON PROFILE

A Snap-on Profile Manager account is required to complete the process. If you already have a Profile Manager account, log in and go to Step 3.

(You would have a profile manager account if you have previously accessed SureTrack community or ALTUSDrive.)

To create a Profile Manager account, go to profilemanager.mitchell1.com.







Login to your account and select the "Device Management" tab.



Enter your **Diagnostic Tool Pin Code** and **Serial Number** from the Get Connected screen of your Tool (See Step 1 at the beginning of these instructions).

Select the "Secure Vehicle Gateway" tab, then select "Add Secure Credentials".



Enter your "AutoAuth" account username and password and select "Save".

Your Diagnostic Tool is now linked to your
AutoAuth account allowing you to access your
Secure Vehicle Gateways.



Note - Autorization Key is not needed.

