Snap-on®

# SECURE VEHICLE GATEWAY

Using compatible diagnostic tools, now you can seamlessly connect to secure vehicle gateways

EMPOWER

UP

UPGRADE S

CONNECTING YOUR DIAGNOSTIC TOOL FOR USE WITH SECURE VEHICLE GATEWAYS

What you need:

- A compatible Snap-on diagnostic tool with Wi-Fi access
- An authorized AutoAuth account(s)
- A Snap-on® Profile Manager Account

Watch the Getting Connected video @

SNAPON.COM/GATEWAY

GETTING YOUR DIAGNOSTIC TOOL INFORMATION

Make sure your diagnostic tool is connected to Wi-Fi before you start!

1 You'll need some information from your diagnostic tool. Select "**System Settings or Tools**", then "**Get Connected**"

Remember your Device Information:

Serial number:...

Pin Code: ....

Activation Code: ....

Device details…
Serial Number: 123ABC456789
PIN Code: 888888
Activation Code: 88888888

CREATING AN AUTOAUTH ACCOUNT

NOTE - AutoAuth charges a $50 annual fee.

Make sure your diagnostic tool is connected to Wi-Fi before you start!

1 Go to autoauth.com and select "**Register Now**" and create an account.

Remember your Username and Password

....

2 Check your email and verify your account.

3 Login to autoauth.com and follow the link to complete your registration as a "**Service Center Signup / Independent Technician Signup**".

After entering the required information select "**Sign Up**".

4 Select the "**Manage Tools**" tab and enter the required information.

User Profile	Manage Tools	Manage Users

Shop Tools | Add Tool

Pick the Type of Tool

Manufacturer — None Selected

Tool Model — AutoEnginuity

5 When done select "**Add**".

Add

Your AutoAuth account is now complete.

CREATING A SNAP-ON PROFILE

1 A **Snap-on Profile Manager account is required to complete the process**. If you already have a Profile Manager account, log in and go to **Step 3**.
(You would have a profile manager account if you have previously accessed SureTrack community or ALTUSDrive.)

2 To create a Profile Manager account, go to **profilemanager.mitchell1.com**.

3 Login to your account and select the "**Device Management**" tab.

Enter your **Diagnostic Tool Pin Code** and **Serial Number** from the Get Connected screen of your Tool (See Step 1 at the beginning of these instructions).

4 Select the "**Secure Vehicle Gateway**" tab, then select "**Add Secure Credentials**".

Enter your "**AutoAuth**" account username and password and select "**Save**".

5 Your Diagnostic Tool is now linked to your AutoAuth account allowing you to access your Secure Vehicle Gateways.

Note - Autorization Key is not needed.

UPGRADE